

1 Plug in and turn on the laptop/PC and your LCD projector.




2 Connect the LCD projector to the video conference equipment using the VGA to DVi Cable.



3 Connect the laptop/PC to your LCD projector using the VGA cable.

4 Press the **Back** button on the remote control to display the onscreen menu items.

Select **Share** and press **OK** on the remote to share your presentation.



5 The size of the shared image is controlled by pressing the **Minimize** icon (select if required).

Select **Stop Sharing** and press **OK** on the remote when you are finished your presentation.



If your laptop does not display your presentation press + on your keyboard and select **"Duplicate"**.

You may also need to change your resolution to 1280x720.

