

Laptop/PC Connection with LCD Projector – Presenter Site


To connect and display your laptop/pc image:

1. Plug in and turn on your laptop/pc and your LCD projector.
2. Connect the laptop/pc to your LCD projector and the LCD projector to the video conference equipment (see image below).




Note: The PC image will always be displayed on the LCD projector but you will control what the far end site sees with the Tandberg Remote Control

3. Press the **Presentation** button to display your laptop/pc image to the far end site. Press it again to return to the **Main Camera** view. (You can also use **Main Cam** and **PC Video Source** buttons to do the same thing)



If your laptop does not display your presentation press on your keyboard and select "Duplicate".



You may also need to change your resolution to 1024x768.

For further assistance, contact the Service Desk 204-940-8500 Option 4 or toll-free 1-866-999-9698 Option 4