



- 1 Plug in and turn on the laptop/PC.



- 2 Connect the laptop/PC to your video conference equipment using the VGA to DVI Cable.


- 3 Press the **Back** button on the remote control to display the onscreen menu items.



Select **Share** and press **OK** on the remote to share your presentation.



- 4 The size of the shared image is controlled by pressing the **Minimize** icon (select if required).

Select **Stop Sharing** and press **OK** on the remote when you are finished your presentation.



If your laptop does not display your presentation press  +  on your keyboard and select **"Duplicate"**.

You may also need to change your resolution to 1280x720.

