


**1** Plug in and turn on the laptop/PC.



**2** Connect the laptop/PC to your video conference equipment using the VGA or HDMI Cable.


**3** Press the **Back** button on the remote control to display the onscreen menu items.



Select **Share** and press **OK** on the remote to share your presentation.



**4** The size of the shared image is controlled by pressing the **Minimize** icon (select if required).

Select **Share>Stop Sharing** and press **OK** on the remote when you are finished your presentation.



If your laptop does not display your presentation press  +  on your keyboard and select **"Duplicate"**.

You may also need to change your resolution to 1280x720.

