

1 Plug in and turn on the laptop/PC and your LCD projector.




2 Connect the LCD projector to the video conference equipment using the VGA or HDMI Cable.



3 Connect the laptop/PC to your LCD projector using the VGA or HDMI cable.

4 Press the **Presentation** button to display your laptop/PC image to the far end site. Press it again to return to the **Main Camera** view. (You can also use **Main Cam** and **PC Video Source** buttons to do the same thing.)

! The PC image will always be displayed on the LCD projector but you will control what the far end site sees with the Tandberg Remote Control.



If your laptop does not display your presentation press **Windows + P** on your keyboard and select **“Duplicate”**.

You may also need to change your resolution to 1280x720.

